



MAD DUCK OUTDOORS

SiloFlag™ Motion Top

Features

- ❖ Legal in all states
 - No motor
 - No electric power
 - No batteries
- ❖ Moves several Silhouette decoys on a single cord
- ❖ Able to move several cords at once
- ❖ Lightweight
- ❖ Uses existing decoys
- ❖ Better than a flag
- ❖ Patent Pending

Description

If you thought a flag was the best thing to come around in attracting far away geese, wait until you see this! Now with our SiloFlag™ motion top you can move one to several strings of silhouettes at a flock of geese. You have to see it to believe it!

No longer will a hunter have to wait for the wind to blow or to drag heavy and expensive motors into the field to make motion in their decoys. Now a hunter can make motion, when they want and how they want. They have the control to move as many or as few decoys as they want. They have the control to move them aggressively or just slightly. They can respond with the decoys to how they feel the birds need to be worked. When you rotate a silhouette decoy 90 degrees it appears to completely disappear. Then when you release it, the decoy will seem to reappear. There is no other product like this on the market!

Typically 6 silhouettes will get placed on one activation string and one hunter can easily control three strings or more with one hand through a flag port on his blind. That is eighteen silhouettes flagging at far away geese to get their attention. Once the flock gets closer you would slow down on the motion to make it more realistic.

Now you can hunt with an all silhouette spread of decoys and have motion in your spread also. You can even use your existing decoys with this system with only a slight modification of drilling two holes into the decoy.

Existing decoys can be used with this motion top, but we are recommending Avalanche

decoys to be used with this motion stake. Avalanche decoys are the only fully flock silhouette on the market. Even Real Geese silhouettes have shine when waved back and forth. So fully flock decoys are the best way to SiloFlag for waterfowl.



An Avalanche Decoys silhouette on a SiloFlag™ motion top

Specifications

The SiloFlag™ motion top is designed to sit on the decoy stake and provide rotary motion to the silhouette decoys mounted to them. The top is made from Hi-impact polystyrene. The motion top can use existing silhouettes that only need to be altered slightly.

The only altering of the decoy that is required is to cut of the legs if they hang down too far and to drill two 3/16" holes that are 3/4" of an inch on center to fasten the silhouette to the motion stake. If the hunter makes a mistake drilling his holes or if the holes wear larger the Fastening Washers CNC-07 are used to secure the decoy from falling or blowing off the motion top. The motion top also comes with a screw hole for permanent attachment of the silhouette to the motion top if preferred. Some decoys with legs may require removal of the legs so they do not interfere with the activation cord.

Ordering Information

CNC-04	SiloFlag™ Motion Top - 3 Pack
CNC-05	Decoy Support/End Stake – 3 Pack
CNC-06	Line Set – 1 Activation Cord Set
CNC-07	Fastening Washer – 6 Pack
CNC-13	SiloFlag™ - Starter 6 Pack